

Concept Question 2-15: Why does a pn-junction diode have a non-zero forward-bias voltage V_F ?

In the absence of a voltage across the diode, the two sets of carriers diffuse away from each other at the edge of the junction, generating an associated built-in potential barrier (voltage), called the **forward-bias voltage** or **offset voltage** V_F .

